lenovo®

Lenovo W500
Bluetooth Keyboard
User Guide

CE

Downloaded from www.Manualslib.com manuals search engine

ENGLISH

Lenovo Bluetooth Keyboard W500

Overview of the main unit



USB charging cable

Specifications:

- OS: Windows 8 and above, Android 4.0 and above.
- Bluetooth 3.0
- 200mAh lithium polymer battery
- Transmission distance: 10 m
- Operation temperature: 0 ~ 45°C
- Storage temperature: -40 ~ +60°C

Downloaded from www.Manualslib.com manuals search engine

Shortcut Keys



❶ **Windows:** call the “IE browser”; **Android:** call the main interface.
❷ Select the “text being entered” from left to right.
❸ Select the “text being entered” from right to left.



About the LED indicator

LED	Light signal	Meaning
Bluetooth LED (blue)	Blink once per second	Is in pairing mode
	Blink twice per second	Is in reconnecting mode
	On for 2 seconds	Just connected
Battery LED (amber)	Blink once per second	Battery level is below 15%
	On/off	On when battery is charging. Off when charging is complete

Downloaded from www.Manualslib.com manuals search engine

Get started

Slide the power button on the side of the keyboard to the “|” position. The Bluetooth indicator will turn blue.

1. If the keyboard has not been paired with any device, it will enter automatic pairing mode. The Bluetooth indicator flashes once per second.
2. If the keyboard has been paired before and you want to pair a new device, please press the “Pair” button for over 2 seconds until the Bluetooth indicator flashes once per second. After your device find the keyboard, please follow the pairing steps and instructions on the screen to complete the pairing. (For detailed pairing operations, please see the instructions below.)
3. If the two paired devices have both been successfully connected to the keyboard, please press for three seconds to switch between the two devices.

Pairing

Windows 8.1/Windows 8 operating system

I. Tablet

1. Press the “Windows” key, and then enter “Bluetooth Settings” in the “Search” bar.
2. After the system detects the Bluetooth keyboard, please select “Lenovo W500” and click “Pair”.



3. When “Connected” is displayed, the pairing is successfully completed.



Downloaded from www.Manualslib.com manuals search engine

II. Notebook or PC

1. Find the “Bluetooth Devices” in the task bar.

2. Right click to bring up the list as shown. Left click to select “Add a Bluetooth Device”.



3. Select “Bluetooth” and then “Add a device”. Find “Lenovo W500”.



4. Click “Lenovo W500” and then “Pair”.



Downloaded from www.Manualslib.com manuals search engine

5. When “Connected” is displayed, the keyboard is successfully connected and ready for use.



Android 4.0 or later

1. Find “Settings” on the main interface.

2. Click “Settings” to enter the “Settings” main interface. Please make sure that “Bluetooth” is set on “ON”.



3. Click “Bluetooth” and then “Search for Device”. Find and then click “Lenovo W500” to pair.



Downloaded from www.Manualslib.com manuals search engine

4. When “Connected” is displayed, the keyboard is successfully paired and ready for use.



Recharging the battery

If the red indicator of the keyboard keeps flashing, the keyboard needs to be charged. Please use the USB charging cable to connect a PC and the keyboard. When the battery is being recharged, the indicator will stay amber. When the battery is fully recharged, the amber light will go off. The keyboard can work normally when the battery is being recharged.

Troubleshooting

I. If you encounter connection problems when using the keyboard, please take the following steps.

1. Power off and then restart your keyboard.
2. Turn off the computer’s Bluetooth function, and turn it on again.
3. Clear the previously paired Bluetooth keyboard device from the computer. Try to pair and connect again.
   When the computer fails to detect the Bluetooth keyboard, 1) check whether the Bluetooth keyboard is in pairing code state; 2) check whether the battery is fully recharged.
   (When the LED indicator keeps flashing amber, you need to recharge the keyboard.)
4. Open “Device Manager” in the “Computer Management” of Windows 8.1/ Windows 8/Windows 7 to select “Bluetooth”. Select “Generic Bluetooth Radio Properties” and then “Power Management” in the pop-up dialog box. Do not select “Allow the computer to turn off this device to save power”.



Downloaded from www.Manualslib.com manuals search engine

II. If an Android system does not support all or some of the shortcut keys, please switch to Android input method or Google input method.

III. If the keyboard and the device fail to pair, please take the following steps.

1. Please check whether the device's Bluetooth protocol is 3.0 or above.
   1) Open "Device Manager" and find "Bluetooth".



   2) Click the ▷ in front of "Bluetooth" to view its version information.



Downloaded from www.Manualslib.com manuals search engine

РУССКИЙ

Клавиатура Lenovo Bluetooth W500

Обзор основного устройства



Кабель для подзарядки USB

Характеристики:

- ОС: Windows 8 и выше, Android 4.0 и выше.
- Bluetooth 3.0
- Литий-полимерный аккумулятор 200 мА/ч
- Расстояние передачи: 10 м
- Рабочая температура: 0 ~ 45°C
- Температура хранения: -40 ~ +60°C

Downloaded from www.Manualslib.com manuals search engine

Клавиши быстрого доступа



❶ Вызов приложения для работы с эл. почтой по умолчанию.
❷ **Windows:** запуск браузера IE; **Android:** запуск главного интерфейса.
❸ Выберите текст для ввода слева направо.
❹ Выберите текст для ввода справа налево.



Общие сведения о светодиодном индикаторе

Цвет индикатора	Световой сигнал	Значение
Индикатор Bluetooth (синий)	Мигает каждую секунду	Переход в режим связи
	Мигает два раза в секунду	Переход в режим повторной установки связи
	Горит в течение 2 секунд	Только что выполнено подключение
Индикатор аккумулятора (желтый)	Мигает каждую секунду	Уровень аккумулятора ниже 15%
	Горит/не горит	Горит, если аккумулятор заряжается. Не горит, если аккумулятор заряжен

Downloaded from www.Manualslib.com manuals search engine

Приступая к работе

Переведите кнопку питания сбоку клавиатуры в положение «|».
Светодиодный индикатор Bluetooth станет синим.

1. Если клавиатура не была связана с каким-либо устройством, она автоматически перейдет в режим связи. Индикатор Bluetooth мигает каждую секунду.
2. Если связь с клавиатурой была установлена ранее и теперь требуется установить связь с новым устройством, нажмите кнопку «Связь» и удерживайте ее не менее 2-х секунд, до тех пор пока индикатор Bluetooth не начнет мигать с частотой один раз в секунду. После обнаружения клавиатуры устройством следуйте инструкциям на экране по установлению связи, чтобы завершить процесс. (Более подробная информация об установлении связи приведена ниже.)
3. Если оба связанных устройства подключились к клавиатуре, нажмите кнопку и удерживайте ее в течение трех секунд, чтобы переключиться от одного устройства к другому.

Установление связи

Операционная система Windows 8.1/Windows 8

I. Планшет

1. Нажмите клавишу Windows, затем введите «Параметры Bluetooth» в строке поиска.
2. После обнаружения системой клавиатуры Bluetooth выберите пункт Lenovo W500 и щелкните пункт «Связать».




Управление устройствами Bluetooth
Ваш компьютер выполняет поиск устройств Bluetooth и может быть обнаружен ими.
Lenovo W500
Готово к созданию связи
Связать

Downloaded from www.Manualslib.com manuals search engine

3. Отображение строки «Подключено» означает, что связь успешно выполнена.



II. Ноутбук или ПК

1. Найдите пункт «Устройства Bluetooth» на панели задач.

2. Щелкните правой кнопкой мыши, чтобы вывести список, как показано на рисунке. Щелкните правой кнопкой мыши для выбора пункта «Добавление устройства Bluetooth».



3. Выберите пункт Bluetooth, затем «Добавить устройство». Найдите пункт Lenovo W500.



Downloaded from www.Manualslib.com manuals search engine

4. Щелкните пункт Lenovo W500, затем выберите пункт «Связать».



5. Надпись «Подключено» означает, что клавиатура успешно подключена и готова к использованию.



Android 4.0 и выше

1. Найдите пункт «Настройки» в главном интерфейсе.

Настройки

2. Щелкните «Настройки», чтобы перейти в главный интерфейс «Настройки». Убедитесь, что для параметра Bluetooth выставлено значение «ВКЛ».

Downloaded from www.Manualslib.com manuals search engine

3. Щелкните пункт Bluetooth, затем выберите «Поиск устройств». Найдите и щелкните пункт Lenovo W500 для установки связи.



4. Надпись «Подключено» означает, что клавиатура успешно связана и готова к использованию.



Перезарядка аккумулятора

Если на клавиатуре продолжает мигать красный индикатор, это означает, что клавиатуре требуется подзарядка. Используйте кабель USB для подзарядки, соединив им ПК и клавиатуру. Если аккумулятор подзаряжается, индикатор будет гореть желтым цветом. Если аккумулятор полностью заряжен, желтый индикатор отключится. При подзарядке аккумулятора клавиатура полностью работоспособна.

Устранение неполадок

I. При обнаружении неполадок, связанных с подключением клавиатуры, выполните следующие действия.

1. Выключите и снова включите клавиатуру.
2. Выключите функцию Bluetooth на компьютере и снова включите ее.
3. Удалите с компьютера ранее связанную клавиатуру Bluetooth. Попробуйте повторить привязку.
   Если компьютер не обнаруживает клавиатуру Bluetooth, 1) проверьте, находится ли клавиатура Bluetooth в режиме связи; 2) проверьте, полностью ли заряжен аккумулятор.
   (Если индикатор мигает желтым цветом, необходимо подзарядить аккумулятор клавиатуры.)

Downloaded from www.Manualslib.com manuals search engine

4. Откройте диспетчер устройств в разделе «Управление компьютером» ОС Windows 8.1 / Windows 8 / Windows 7, чтобы выбрать пункт Bluetooth. Выберите пункт «Свойства: Generic Bluetooth Radio», затем в появившемся диалоговом окне пункт «Управление электропитанием». Не выбирайте пункт «Разрешить отключение этого устройства для экономии энергии».



II. Если система Android не поддерживает некоторые или все клавиши быстрого доступа, переключитесь на метод ввода Android или метод ввода Google.

III. Если клавиатура и устройства не могут связаться друг с другом, выполните следующие действия.

1. Проверьте, поддерживает ли устройство протокол Bluetooth 3.0 или выше.
   1) Откройте диспетчер устройств и найдите пункт Bluetooth.



   2) Щелкните ▷ перед пунктом Bluetooth, чтобы просмотреть сведения о версии.



Downloaded from www.Manualslib.com manuals search engine

FCC Statement

United States of America Certification Number:

FCC ID: EMJKW500

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.”

FCC Caution:
Changes or modifications not expressly approved by the part responsible for compliance could void the user’s authority to operate the equipment.
This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Radiation Exposure Statement:
The product comply with the US/Canada portable RF exposure limit set forth for an uncontrolled environment and are safe for intended operation as described in this manual. The further RF exposure reduction can be achieved if the product can be kept as far as possible from the user body or set the device to lower output power if such function is available.

This transmitter must not be co-located or operating in conjunction with any otherantenna or transmitter.

Responsible Party:
Lenovo (United States) Incorporated
1009 Think Place-Building One

Downloaded from www.Manualslib.com manuals search engine

Morrisville, NC 27560
Telephone: 1-919-294-5900

IC Statement

Canada Certification Number
Canada Numéro de Certification

IC: 4251A-KW500

This device complies with RSS-210 of the Industry Canada Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Ce dispositif est conforme à la norme CNR-210 d'Industrie Canada applicable aux appareils radio exempts de licence. Son fonctionnement est sujet aux deux conditions suivantes: 1) le dispositif ne doit pas produire de brouillage préjudiciable, et 2) ce dispositif doit accepter tout brouillage reçu, y compris un brouillage susceptible de provoquer un fonctionnement indésirable.

Low Power License-Exempt Radio Communication Devices (RSS-210)
Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

Permis d'émission à faible puissance – Cas des appareils de communications radio
L'utilisation de ce dispositif est autorisée seulement aux conditions suivantes: (1) il ne doit pas produire de brouillage, et (2) l'utilisateur du dispositif doit être prêt à accepter tout brouillage radioélectrique reçu, même si ce brouillage est susceptible de compromettre le fonctionnement du dispositif.

Certification in Singapore

Complies with IDA Standards DB102306

Certification in Russia

EAC

Certification in Indonesia

33475/SDPPI/2014
3876

CE Lenovo, Einsteinova 21, 851 01 Bratislava, Slovakia

Products intended for sale within the European Union are marked with the Conformité Européenne (CE) Marking, which indicates compliance with the applicable Directives and European Norms, and amendments, identified below.

Downloaded from www.Manualslib.com manuals search engine

Hereby, **Lenovo (Singapore) Pte. Ltd.**, declares that this **Lenovo Wireless Keyboard** is in compliance with the essential requirements and other relevant provisions of Directive 1999/5/EC.

Česky [Czech]
Lenovo (Singapore) Pte. Ltd., tímto prohlašuje, že tento **Lenovo Wireless Keyboard** je ve shodě se základními požadavky a dalšími příslušnými ustanoveními směrnice 1999/5/ES.

Dansk [Danish]
Undertegnede **Lenovo (Singapore) Pte. Ltd.** erklærer herved, at følgende udstyr **Lenovo Wireless Keyboard** overholder de væsentlige krav og øvrige relevante krav i direktiv 1999/5/EF.

Eesti [Estonian]
Käesolevaga kinnitab **Lenovo (Singapore) Pte. Ltd.** seadme **Lenovo Wireless Keyboard** vastavust direktiivi 1999/5/EÜ põhinõuetele ja nimetatud direktiivist tulenevatele teistele asjakohastele sätetele.

Suomi [Finnish]
Lenovo (Singapore) Pte. Ltd. vakuuttaa täten että **Lenovo Wireless Keyboard** tyyppinen laite on direktiivin 1999/5/EY oleellisten vaatimusten ja sitä koskevien direktiivin muiden ehtojen mukainen.

Ελληνική [Greek]
ΜΕ ΤΗΝ ΠΑΡΟΥΣΑ **Lenovo (Singapore) Pte. Ltd.** ΔΗΛΩΝΕΙ ΟΤΙ **Lenovo Wireless Keyboard** ΣΥΜΜΟΡΦΩΝΕΤΑΙ ΠΡΟΣ ΤΙΣ ΟΥΣΙΩΔΕΙΣ ΑΠΑΙΤΗΣΕΙΣ ΚΑΙ ΤΙΣ ΛΟΙΠΕΣ ΣΧΕΤΙΚΕΣ ΔΙΑΤΑΞΕΙΣ ΤΗΣ ΟΔΗΓΙΑΣ 1999/5/ΕΚ.

Deutsch [German]
Hiermit erklärt **Lenovo (Singapore) Pte. Ltd.** dass sich das Gerät **Lenovo Wireless Keyboard** in Übereinstimmung mit den grundlegenden Anforderungen und den übrigen einschlägigen Bestimmungen der Richtlinie 1999/5/EG befindet.

Magyar [Hungarian]
Alulírott, **Lenovo (Singapore) Pte. Ltd.** nyilatkozom, hogy a **Lenovo Wireless Keyboard** megfelel a vonatkozó alapvetõ követelményeknek és az 1999/5/EC irányelv egyéb elõírásainak.

Íslenska [Icelandic]
Hér með lýsir **Lenovo (Singapore) Pte. Ltd.** yfir því að **Lenovo Wireless Keyboard** er í samræmi við grunnkröfur og aðrar kröfur, sem gerðar eru í tilskipun 1999/5/EC

Downloaded from www.Manualslib.com manuals search engine

Lietuvių [Lithuanian]
Šiuo **Lenovo (Singapore) Pte. Ltd.** deklaruoja, kad šis **Lenovo Wireless Keyboard** atitinka esminius reikalavimus ir kitas 1999/5/EB Direktyvos nuostatas.

Latviski [Latvian]
Ar šo **Lenovo (Singapore) Pte. Ltd.** deklarē, ka **Lenovo Wireless Keyboard** atbilst Direktīvas 1999/5/EK būtiskajām prasībām un citiem ar to saistītajiem noteikumiem.

Malti [Maltese]
Hawnhekk, **Lenovo (Singapore) Pte. Ltd.** jiddikjara li dan **Lenovo Wireless Keyboard** jikkon-forma mal-ħtiġijiet essenzjali u ma provvedimenti oħrajn relevanti li hemm fid-Dirrettiva 1999/5/EC.

Nederlands [Dutch]
Hierbij verklaart **Lenovo (Singapore) Pte. Ltd.** dat het toestel **Lenovo Wireless Keyboard** in overeenstemming is met de essentiële eisen en de andere relevante bepalingen van richtlijn 1999/5/EG.

Norway [Norwegian]
Lenovo (Singapore) Pte. Ltd. erklasrer herved at utstyret **Lenovo Wireless Keyboard** er I samsvar med de grunñleggende kravog 0vrige relevante krav i d i rakti v 1999/5/EF.

Polski [Polish]
Niniejszym **Lenovo (Singapore) Pte. Ltd.** oświadcza, że **Lenovo Wireless Keyboard** jest zgodne z zasadniczymi wymaganiami oraz innymi stosownymi postanowieniami Dyrektywy 1999/5/WE

Slovensky [Slovak]
Lenovo (Singapore) Pte. Ltd. týmto vyhlasuje, že **Lenovo Wireless Keyboard** spĺňa základné požiadavky a všetky príslušné ustanovenia Smernice 1999/5/ES.

Slovensko [Slovenian]
Lenovo (Singapore) Pte. Ltd. izjavlja, da je ta **Lenovo Wireless Keyboard** v skladu z bistvenimi zahtevami in ostalimi relevantnimi določili direktive 1999/5/ES.

Español [Spanish]
Por medio de la presente **Lenovo (Singapore) Pte. Ltd.** declara que el **Lenovo Wireless Keyboard** cumple con los requisites esenciales y cualesquiera otras disposiciones aplicables o exigibles de la Directiva 1999/5/CE.

Downloaded from www.Manualslib.com manuals search engine

Svenska [Swedish]
Härmed intygar **Lenovo (Singapore) Pte. Ltd.** att denna **Lenovo Wireless Keyboard** står I överensstämmelse med de väsentliga egenskapskrav och övriga relevanta bestämmelser som framgår av direktiv 1999/5/EG.

Português [Portuguese]
Lenovo (Singapore) Pte. Ltd. declara que este **Lenovo Wireless Keyboard** está conforme com os requisitos essenciais e outras disposições da Directiva 1999/5/CE.

Français [French]
Par la présente **Lenovo (Singapore) Pte. Ltd.** déclare que l'appareil **Lenovo Wireless Keyboard** est conforme aux exigencies essentielles et aux autres dispositions pertinentes de la directive 1999/5/CE.

Downloaded from www.Manualslib.com manuals search engine

EC Declaration of Conformance

Product: Lenovo BT Multi-OS Keyboard W500
Model: Lenovo W500
Trade Name: Lenovo

We, Primax Electronics Ltd., declare under sole responsibility that the above products, manufactured by:

Phone: 886(2)2798 9008
Fax: 886(2) 8797 1565
Primax Electronics Ltd.
No. 669,Ruey Kuang Road,
Neihu ,Taipei Taiwan, R.O.C.

to which this declaration relates, is in conformity with the requirements of the following EC Directives:

- Council Directive 1999/5/EC of the European Parliament and of the council on radio equipment and telecommunications terminal equipment.
- Council Directive 2006/95/EC on the harmonization of the laws of the Member States relating to electronic equipment designed for use within certain voltage limits.
- Council Directive 2004/108/EC on the approximation of the laws of the member states relating to Electromagnetic Compatibility
- Council Directive 2011/65/EU of the European Parliament and of the council on the restriction of the use of certain hazardous substances in electrical and electronic equipment

Conformity with these Directives has been assessed for this product by demonstrating compliance to the following harmonized standards:

EN 300 328 V1.8.1 (2012-06)
EN 301 489-1 V1.9.2 (2011-09)
EN 301 489-17 V2.2.1 (2012-09)
EN 62479: 2010
EN 60950-1:2006 + A11:2009 +A1:2010 +A12:2011
EN 50581: 2012

Signed: _____ Date: 2014/02/12
C.T. Huang, Director
Compliance Department
Last two digits of the year in which the CE marking was affixed: 14

Place of Issue: Taiwan
Date: February 12, 2014
Ref No: CE_DoC_14-001

Downloaded from www.Manualslib.com manuals search engine